


UNLOADING SAMPLES FROM CRYOPORT EXPRESS® COMBO SHIPPER (CXCB1)

SECTION A


UNLOADING SAMPLES

STEP 1



Remove top accessory tray to load commodity. Lift upwards on the white tabs.

STEP 2




Remove documents and non-temperature sensitive items/commodity from the top accessory tray. Dispose of the top accessory tray when finished.

STEP 3


If you are expecting to receive additional non-temperature sensitive accessories with your shipment, please see the “How to Include and Remove Accessories in the Standard/Combo Shipper” instructions.

STEP 4

RELEASING THE RETENTION BAND




Once the top accessory tray is removed, you will need to release the retention band on the shipper plug. Pull the small circle handle up to release the locking tab.



Unlatch and pull apart the straps.

STEP 5




Wear Safety Gloves. Hold the shipper plug in one hand. Hold the blue Safepak® straps with other hand. Pull the shipper plug upwards and out.

STEP 6



Put the shipper plug to aside. Gently pull upwards on the blue Safepak® straps. Remove sample bag completely and place on a flat surface.

STEP 7



Hold bag with one gloved hand. Use scissors to cut off end of the Safepak® bag. Remove end of bag completely to reveal sample container(s).

STEP 8




Remove contents and discard the Safepak® bag.

STEP 9



WARNING! Do not leave any samples inside of the shipper. Replace the shipper plug. Push the plug fully into place.

STEP 10




Ensure the hole on the shipper plug and the gray hole on the dewar are aligned. Turn shipper plug to align, if necessary. Also ensure the retention band handles are not overlapping the holes.


**IF THE DRY SHIPPER DOES NOT EMIT VAPOR WHEN PLUG IS REMOVED
PLEASE CONTACT CUSTOMER SERVICE IMMEDIATELY, BY CALLING (949) 470-2305 OR EMAIL CS@CRYOPORT.COM**

UNLOADING SAMPLES FROM CRYOPORT EXPRESS® COMBO SHIPPER (CXCB1)



STEP 11 SECURING THE RETENTION BAND




Place the smaller circle handle under the other strap and pull the handle through the slit.



Place your thumb on the word "PUSH" and pull the straps away from each other to place the tab with the word PUSH under the tab with the green check mark.



Ensure the PUSH tab is behind the green check mark tab.




The green check mark will be visible when secured.

SECTION B

PACKAGING THE SHIPMENT

STEP 1




If any label was used in this area for your shipment, place the enclosed "EMPTY" label over it.

STEP 2



Remove Stop Insert from inside shipping envelope on flap "B". Throw away ONLY the Stop Insert.

STEP 3



- Close flaps making sure to have flap "B" showing on the outside of the white carton.
- For International shipments: REMOVE AND SIGN ALL FOUR (4) COPIES OF THE COMMERCIAL INVOICES.
- Place all four (4) signed copies of Commercial Invoices back inside shipping envelope on Flap "B" behind Air Waybill.

SECTION C

SHIPPING



Seal top of white carton with packaging tape making sure to have flap "B" showing on the outside of the white carton.

Please return empty shipper to Cryoport within 24 hours.



For those shipments containing regulated dangerous goods/hazardous materials, the shipper is responsible for correctly preparing the shipment according to the current International Air Transport Association (IATA) and International Civil Aviation Organization (ICAO) dangerous goods regulations.

This includes correct identification, classification, packaging, dangerous goods markings and labeling as well as completion of all pertinent and required documentation. The shipper is the customer who is preparing the shipment at each leg in the transportation of the dry dewar packaging.

**24-hour Help Line
(949) 470-2305**

Cryoport Systems, LLC • 17305 Daimler St. • Irvine, CA 92614

Phone: 1-949-470-2300 | Fax: 1-949-470-2306

www.cryoport.com • e-mail contact: cs@cryoport.com